

FPT NAFTA Training Course Sequence



Courses and Sequence

Essential Training

FPT_101 Fundamental overview of FPT engines
 FPT_ET101 Fundamental course for electrical diagnostics

FPT_ET102 PT-Box Diagnostics Course

FPT_AT101 After Treatment Overview

Basic Engine Service

FPT_BER22 R22 basic engine top end service, adjustments
FPT_BEF5 F5 basic engine top end service, adjustments
FPT_BENEF NEF basic engine top end service, adjustments
FPT_BECUR Cursor basic engine top end service, adjustments

After Treatment Systems

FPT_AT101 After Treatment Overview

FPT_ATT4i Specialized course for Tier 4a, Tier 4i (Denox 2.1)

FPT_ATT4b Specialized course for Tier 4b (Denox 2.2)


Advanced Engine Diagnostic

FPT_AD01 Common Rail fuel injection systems
 FPT_AD02 Unit Fuel injector injection systems
 FPT_AD03 Rotary Pump Fuel Injection systems

Power Generation and Marine Engines

FPT_ME01 Marine application of the N and C series engines

FPT_PG01 FPT Engines in generator set applications



Download Course Sequence and Prerequisites

Contact Us: FPTenginetraining@cnhind.com



Prerequisites For Advanced Courses

- Completion of the "Basic Training Series" and Basic Engine classes meet the prerequisites necessary to participate in advanced diagnostic classes
- FPT_AD01 Advanced Diagnostics for Common Rail Fuel Injection Systems
 - Requires completion of:
 - ✓ "Basic Training Series" (FPT_101, FPT_AT101, FPT_ET101, and FPT_102)
 - ✓ A minimum of one Basic Engine FPT_BE*** using this fuel system
- After Treatment Classes
 - FPT_ATT4i Specialized course for Tier 4a, Tier 4i (Denox 2.1)
 - or
 - FPT_ATT4b Specialized course for Tier 4b (Denox 2.2)
 - Requires completion of:
 - FPT_AT101, FPT_ET101 and FPT_ET102

